



Issued: 08/12/2020
RE: Technical Bulletin – Cutting Recommendation for ROCKWOOL Cavityrock® Black

ROCKWOOL Cavityrock® Black is designed, tested and approved for use in cavity wall and rainscreen systems that require a black finish due to the material being visible behind the cladding. This black finish is for aesthetic appeal where any visible insulation between the cladding joints will appear black rather than the natural insulation colour.

When installation requires cutting of the ROCKWOOL Cavityrock® Black, the insulation should be laid down on a rigid surface with the black finish facing up. Be cautious to maintain a minimum of a 1/2" distance between the hilt of the knife and the facing of the insulation to avoid puncturing the black mat facing.

In order to achieve a sharp and even cut, a serrated insulation knife should be used. It is advised to use extra care and a slow and steady motion when cutting using a saw-like motion.

To minimize scratching of the black mat facing surface, keep the product in its original packaging until installation at which points when the plastic is removed carry the boards wool side to face side, don't stack facing to facing. Use plastic from the packaging on the facing when carrying up scaffolding to protect the top layer.

For more information, please contact the ROCKWOOL Technical Support at the phone and email address below.

ROCKWOOL Technical Support
1-877-823-9790
contactus@rockwool.com