

Ablative Coating

Tools required

- Paint brush
- Spray applicator

Ancillary products

Ablative Coated Batt

Fixing and application

1. Ensure that substrates and services to be coated are clean, dry and free from contaminants.
2. Coating to bare stone mineral wool can be applied by brush or spray applied.
3. Ensure that the coating forms complete coverage and that no bare mineral wool can be seen.



Health & safety

The mechanical effect of fibres in contact with skin may cause temporary itching.



Cover exposed skin
When working in unventilated area wear disposable face mask.



Clean area using vacuum equipment.



Waste should be disposed of according to local regulations.



Rinse in cold water before washing.



Ventilate working area if possible.



Wear goggles when working overhead.