

HARDROCK® Multi-Fix Angle Fillets

Tools required

- Fine toothed saw or panel saw
- Tape measure

Installation

- HARDROCK® Multi-Fix Angle Fillets must be installed in dry conditions.
- With the white glass fleece facing outward, place the Angle Fillet along the 90° abutment at the interface between the horizontal and vertical surfaces.
- Fix the Angle Fillet to the horizontal surface using a compatible adhesive.
- Angle Fillets can be cut easily using a fine-tooth saw.



Health & safety

The mechanical effect of fibres in contact with skin may cause temporary itching.



Cover exposed skin
When working in unventilated area wear disposable face mask.



Clean area using vacuum equipment.



Waste should be disposed of according to local regulations.



Rinse in cold water before washing.



Ventilate working area if possible.



Wear goggles when working overhead.