

ROCKLAP H&V Pipe Sections

Tools required

- Sharp insulation knife or insulation saw
- Tape measure
- Rule

Ancillary products

Self adhesive aluminium foil tape, ROCKLAP Pipe Supports

Fixing and application

1. ROCKLAP H&V sections are preformed circular sections manufactured to suit various pipe diameters.
2. The product is supplied pre-split and hinged for ease of installation.
3. Open up the H&V section and place securely around the pipe.
4. Fix in place by peeling protective tape from self-adhesive lap and pressing lap smoothly over joint.
5. Where adjacent sections abut, approved 75 mm wide aluminium tape to be used to maintain integrity of the vapour barrier.
6. For chilled water/CWS attention to be paid to maintaining integrity of the vapour barrier.
7. At termination points, insulation edges to be over-taped and returned to the piping surface.
8. Where the insulation abuts pipe supports, the insulation is to be taped to all supports.

Handling & storage

ROCKLAP H&V Pipe Sections are easy to cut to any shape with a sharp knife. When stored outside, avoid contact with the ground and cover with a securely anchored waterproof sheet.

Maintenance

Once installed ROCKLAP H&V Pipe Sections shouldn't require any maintenance.



Health & safety

The mechanical effect of fibres in contact with skin may cause temporary itching.



Cover exposed skin
When working in unventilated area wear disposable face mask.



Clean area using vacuum equipment.



Waste should be disposed of according to local regulations.



Rinse in cold water before washing.



Ventilate working area if possible.



Wear goggles when working overhead.