

Intumescent Pipewrap Roll

Tools required

- Sharp knife or scissors

Ancillary products

Acoustic Intumescent Sealant

Fixing and application


The product is intended to be wrapped around the outside diameter of combustible pipework or the outside diameter of insulation on pipework and is secured by means of the integral self-adhesive strip.

1. Check that pipe surface and substrate are clean and clear of any debris.
2. Install the correct number of wraps for the service type and ensure the correct number of layers of wrap as detailed in the performance section of the data sheet.
3. Install the wrap into the wall or floor recessed by 5mm from the face of the wall or floor.
4. Fill the annular space with ROCKWOOL® FIREPRO® Acoustic Intumescent Sealant to seal off the 5mm gap to the edge of the substrate.
5. Maintain a record of the installation.

Under fire conditions, the intumescent material expands against the structure and fills the void left by the burnt out plastic and/or insulation.

Maintenance

During normal use, no maintenance is required.



Health & safety

The mechanical effect of fibres in contact with skin may cause temporary itching.



*Cover exposed skin
When working in unventilated area wear disposable face mask.*



Clean area using vacuum equipment.



Waste should be disposed of according to local regulations.



Rinse in cold water before washing.



Ventilate working area if possible.



Wear goggles when working overhead.